



Calculation of slenderness ratio for laced columns with serpentine and crosswise lattices

A.G. Razdolsky

Ein Gedi St. 2/16, Holon 58506, Israel

ARTICLE INFO

Article history:

Received 5 May 2010

Accepted 27 July 2010

Keywords:

Buckling

Laced column

Lattice rigidity

Slenderness ratio

Statically indeterminate structure

ABSTRACT

In contrast to the technique accepted in existing design specifications, a slenderness ratio for laced columns with serpentine or crosswise lattices is determined as a result of consideration of the laced column as a statically indeterminate structure. Recent results of solving the buckling problem for laced columns, on the one hand, and the well known relationship between the slenderness ratio of the compressed bar and its elastic critical force, on the other hand, enable representation of the slenderness ratio of the laced column as a function of the special lattice rigidity parameter and the number panels into which the lattice joints divide the column chords. The obtained curves of the slenderness ratio for columns with a different number of panels are slightly distinguished one from another. As a consequence the single dependence between the modified slenderness ratio of the column and the lattice rigidity parameter can be accepted for columns regardless of the number of panels. This dependence is constructed by enveloping at the top the curves corresponding to fixed numbers of panels. The obtained plots of the modified slenderness ratio for columns with serpentine and crosswise lattices can be applied in designing steel-laced columns.

© 2010 Elsevier Ltd. All rights reserved.

1. Introduction

Design recommendations [1–5] for calculation of the elastic critical force for a laced column are based on the conception of the equivalent slenderness ratio proposed by Engesser in 1891 [6,7]: the buckling problem for a laced column is reduced to calculation of Euler's critical force for the "equivalent" solid pin-ended compressed bar. This approach recognizes the possibility of the only sinusoidal half-wave buckling mode shape for the laced column. In actual fact, laced columns are highly redundant systems and the loss of column stability can occur by various buckling mode shapes depending on a correlation between the chord rigidity and the lattice rigidity. Euler's critical force for a laced column as a statically indeterminate structure can be calculated as a result of solving a two-point boundary value problem for a system of recurrence dependences between the deformation parameters of column cross-sections passing through the lattice joints [8–11]. Recent results of solving the buckling problem for laced columns as a statically indeterminate structure [10,11] disprove Engesser's assumption that the stability problem of the laced column can be reduced to the analogous problem for a continuous solid pin-ended column. In the general case, buckling mode shapes obtained for the column as a statically indeterminate structure take the form

of the irregular curve consisting of several half-waves with unequal amplitudes. The stability analysis of a column as a statically indeterminate structure shows that Euler's critical force is a function of the special rigidity parameter of the column lattice and the number of panels into which the lattice joints divide the column chords. In contrast to the technique accepted in existing design specifications, the equivalent slenderness ratio for laced columns is suggested to determine according to the statically indeterminate scheme. The equivalent slenderness ratio for a laced column is defined as a slenderness ratio of the equivalent solid bar. The pin-ended solid bar is equivalent to the given laced column if the Euler's critical force for the bar equals this for the laced column [6,7,1]. Consequently, the equivalent slenderness ratio for the laced column can also be represented as a function of the mentioned lattice rigidity parameter and of the panel number of the column chords.

2. Relations between Euler's critical force and equivalent slenderness ratio for laced columns

Consider laced columns that consist of two identical longitudinal chords linked by braces forming two mutually parallel lattices. In the following, we will discuss two types of lattice, serpentine (Fig. 1(a)) and crosswise (Fig. 1(b)). Each chord has a solid cross-section with at least a single axis of symmetry. This axis coincides with the axis of symmetry of the whole column cross-section, and is parallel to the lattice planes. The column cross-sections passing

E-mail address: razdols@hotmail.com.

Notation

A	Cross-sectional area of the column chord
A_d	Cross-sectional area of the lattice brace
a	Distance between the column cross-sections passing through the adjacent lattice joints (length of the chord sub-panel for the column with the serpentine lattice (Fig. 1(a)); length of the chord panel for the column with the crosswise lattice (Fig. 1(b)))
n	Number of the chord sub-panels for the column with the serpentine lattice or the chord panel for the column with the crosswise lattice
E	Young's modulus
I	Second moment of inertia of the chord cross-section about its principal axis normal to the lattices
I_0	Second moment of inertia of the whole column cross-section about its principal axis normal to the lattices
N_{cr}	Euler's critical value of the axial compressed force applied to the column chord
N_a	Euler's critical force for the simply supported bar identical in the static-geometry features with the chord panel/sub-panel
N_*	Engesser's critical value of the axial compressed force applied to the column chord
α	Lattice rigidity parameter
φ	Inclination angle of the lattice brace to the column cross-section (Fig. 1)
λ_a	Slenderness ratio of the chord panel/sub-panel
λ_{eq}	Equivalent slenderness ratio of the laced column
λ_m	Modified slenderness ratio of the laced column




Fig. 1. Laced columns with serpentine and crosswise lattices.

through the lattice joints divide each column chord along its length into panels and sub-panels respectively for crosswise and serpentine lattices. Each chord is compressed by an axial force N .

The equivalent slenderness ratio for the laced column is expressed through Euler's critical value N_{cr} of the axial force

$$\lambda_{eq}^2 = \frac{\pi^2 EA}{N_{cr}} \quad (1)$$

where E = Young's modulus and A = the cross-sectional area of the column chord. We will relate the critical force N_{cr} to Euler's force for a simply supported bar identical in the static-geometry features

with the panel or sub-panel of the chord

$$N_a = \frac{\pi^2 EA}{\lambda_a^2} \quad (2)$$

The slenderness ratio of this bar is

$$\lambda_a = a\sqrt{A/I} \quad (3)$$

where a is a length of the chord panel in the case of the crosswise lattice or the chord sub-panel in the case of the serpentine lattice (Fig. 1). The analysis of elastic stability of a laced column as a static indeterminate structure shows that the relative critical force of the column can be represented as a function of the special non-dimensional lattice rigidity parameter α and the number of chord panels or sub-panels [9–11]

$$\frac{N_{cr}}{N_a} = f(\alpha, n). \quad (4)$$

The lattice rigidity parameter depends on the cross-sectional area of lattice braces and the moment of inertia of the chord cross section (Eq. (12) in Razdolsky [10] and Eq. (24) in Razdolsky [11])

$$\alpha = \frac{A_d a^2}{I} \sin 2\varphi \cos \varphi. \quad (5)$$

It is evident from Eqs. (1)–(2) that the equivalent slenderness ratio of the laced column is defined by the relative critical force of column

$$\lambda_{eq} = \lambda_a \sqrt{\frac{N_a}{N_{cr}}}. \quad (6)$$

The lattice rigidity parameter can be also represented as follows

$$\alpha = \frac{2 \tan \varphi}{(1 + \tan^2 \varphi)^{3/2}} \frac{A_d}{A} \lambda_a^2. \quad (7)$$

The ratio of the brace cross-sectional area to the chord cross-sectional area can be also expressed through the rigidity parameter α and the slenderness ratio λ_a

$$\frac{A_d}{A} = \frac{(1 + \tan^2 \varphi)^{3/2}}{2 \tan \varphi} \frac{\alpha}{\lambda_a^2}. \quad (8)$$

We compare the equivalent slenderness ratio calculated for the laced column as a statically indeterminate structure with the slenderness ratio that follows from the Engesser's approach. The Engesser's critical force of the column chord is described by the formula [7, Section 2.18]

$$N_* = \frac{\pi^2 E I_0}{2(na)^2} \left[1 + \frac{\pi^2 I_0}{(na)^2} \frac{1}{mA_d \sin \varphi \cos^2 \varphi} \right]^{-1} \quad (9)$$

where $I_0 = 2I + 0.5A(a/\tan \varphi)^2$ is the second moment of inertia of the whole column cross-section and m is a factor depending on the lattice scheme ($m = 2$ for serpentine lattice and $m = 4$ for crosswise lattice). We neglect the moment of inertia $2I$ of the individual chords in comparison with the second term in the expression of I_0 and express the brace cross-sectional area through the rigidity parameter α according to Eq. (8). The formula Eq. (9) takes the form

$$N_* = \frac{\pi^2 EA}{4n^2 \tan^2 \varphi} \left[1 + \frac{\pi^2}{n^2 \tan^2 \varphi} \frac{\lambda_a^2}{m\alpha} \right]^{-1}. \quad (10)$$

The expression of the equivalent slenderness ratio corresponding to Engesser's approach follows from Eq. (10)

$$\lambda_{eq} = 2\sqrt{\frac{\pi^2 \lambda_a^2}{m\alpha} + n^2 \tan^2 \varphi}. \quad (11)$$

3. Column with a serpentine lattice

Calculation of the equivalent slenderness ratio for laced columns as statically indeterminate structures is based on the relation

Download English Version:

<https://daneshyari.com/en/article/285661>

Download Persian Version:

<https://daneshyari.com/article/285661>

[Daneshyari.com](https://daneshyari.com)